
Hızlı Başlangıç Kılavuzu


1 Pilleri Uzaktan Kumandaya yerleştiriniz

Pil bölmesini açığa çıkarmak için arka kapağı çıkarınız. İki adet **AAA** pil yerleştiriniz. (+) ve (-) işaretlerinin eşleştiğinden emin olunuz (doğru kutuplara dikkat ediniz). Kapağı yerine takınız.

2 Anten kablosunu TV'nize bağlayınız



3 TV'yi prize takınız




4 TV'yi Açın

Güç kablosunun fişini prize takınız. Bekleme LED'i yanacaktır.
Bekleme konumundan çıkıp TV'yi açabilmek için aşağıdakilerden birini yapınız:

1. Uzaktan kumandada bulunan **Bekleme** tuşuna, bir numara tuşuna veya **Program +/-** tuşlarına basınız.

2.a. TV'yi açmak için yan fonksiyon tuşunun ortasına basınız.
b. TV'deki kontrol tuşuna basınız.
c. TV'deki kontrol çubuğunun ortasına basın.



Not: *Rakamlar yalnızca temsilidir Kumanda tuşlarının konumu modele bağlı olarak farklılık gösterebilir.*

5 Diğer Cihazları TV'ye Bağlama

LÜTFEN BAĞLAMADAN ÖNCE HER İKİ ÜNİTENİN DE KAPALI OLDUĞUNA EMİN OLUN. İki üniteyi birbirine bağlamak için uygun kabloyu kullanın.İstediğiniz girişi seçmek için, uzaktan kumandada bulunan Kaynak tuşuna basınız. Ardından ilgili giriş seçeneğini seçin ve **OK** tuşuna basın.



Örnek Bağlantı - HDMI

6 Otomatik Kurulum işlemi

İlk defa açılırken, karşılama ekranı görüntülenecektir. Dilinizi seçin ve **OK** tuşuna basınız. TV'nizi ayarlamak ve kanalları kurmak için ekrandaki talimatları takip edin. Kurulum sihirbazı kurulum sürecince size rehberlik edecektir.


7 TV'nizin internete bağlı olması gerekir

Bir geniş bant sistemine bağlayarak, TV'niz aracılığıyla internet erişimi sağlayabilirsiniz. Çeşitli canlı içeriklerin ve internet uygulamalarının tadını çıkarmak için ağ ayarlarınızın konfigürasyonunu yapmanız gerekir. Bu ayarlar, **Ayarlar** menüsünün altındaki **Ağ** menüsünden yapılandırılabilir.

Kablolu Bağlantı (opsiyonel)
Bir ethernet kablosu aracılığıyla TV'nizi modeminize/yönlendiricinize bağlayınız. TV'nizin arka tarafında bir LAN bağlantısı portu bulunmaktadır. Ağ menüsündeki **Ağ Türü** seçeneğini **Kablolu Aygıt** olarak ayarlayın.

Kablosuz Bağlantı (opsiyonel)
TV'yi kablosuz LAN aracılığıyla internete bağlamak için bir kablosuz LAN modem/yönlendirici gereklidir. Ağ menüsündeki **Ağ Türü** seçeneğini **Kablosuz Aygıt** olarak ayarlayın. Kullanılabilir ağlar listelenecektir. Listeden ağınızı seçiniz ve bağlanmak için **OK** tuşuna basınız. Seçilen ağın parola korumalı olması durumunda, bu ağa bağlanmak için bir parola girmeniz istenebilir.

Kablolu bağlantı



TV'nin arka tarafında bulunan LAN girişi

Kablosuz Bağlantı



8 Uygulamalara Erişim


TV'nizde kurulumu yapılmış olan uygulamalara **Uygulamalar**'a veya **Ana sayfa**'ya menüsünden ulaşabilirsiniz. Ana menüde **Uygulamalar**'a veya **Ana sayfa**'ya gidin, bir uygulamayı vurgulayınız ve başlatmak için **OK** tuşuna basınız.

Quick Start Guide


1 Insert the batteries into the Remote Control

Remove the back cover to reveal the battery compartment. Insert two size **AAA** batteries. Make sure the (+) and (-) signs match (observe correct polarity). Place the cover back on.

2 Connect the antenna to your TV



3 Connect theTV to the mains socket




4 Switch the TV on

Connect the power cord to the mains socket. Then the standby LED lights up. To switch on the TV from standby mode either;

1. Press the **Standby** button, a numeric button or **Programme +/-** button on the remote control

2.a. Press the middle of the side function switch on the TV in
b. Press the control button on the TV
c. Press the centre of the joystick on the TV in



Note: *The figures are for representation only. The position of the buttons may vary depending on the model of your TV.*

5 Connect Other Equipments to the TV

PLEASE ENSURE BOTH UNITS ARE SWITCHED OFF BEFORE CONNECTING. Use the proper cable to connect two units together. To select the desired input, press the **Source** button on the remote control. Then select the related input option and press **OK**.



Example Connection - HDMI

6 Auto Setup procedure

When turned on for the first time, Welcome Screen will be displayed. Select your language and press **OK**. Follow the on screen instructions to set your TV and install channels. The installation wizard will guide you through the setup process.

7 Connect the TV to the Internet

You can access the internet via your TV, by connecting it to a broadband system. It is necessary to configure the network settings in order to enjoy a variety of streaming content and internet applications. These settings can be configured from the **Network** menu located under the **Settings** menu.


Wired Connection (optional)

Connect your TV to your modem/router via an Ethernet cable. There is a LAN port on the rear side of your TV. Set the **Network Type** option in the **Network** menu to **Wired Device**.

Wireless Connection (optional)

A wireless LAN modem/router is required to connect the TV to the Internet via wireless LAN. Set the **Network Type** option in the **Network** menu to **Wireless Device**. Available networks will be listed. Highlight your network from the list and press **OK** to connect. You may be asked to enter a password to connect to the selected network, in case the network is password protected.

Wired Connection



Wireless Connection



8 Access Applications

You can access the applications installed on your TV from **Apps or Home** menu. Scroll to **Apps or Home** on the main menu, highlight an app and press **OK** to launch.

50535885